

使用説明書
BEDIENUNGSANLEITUNG
INSTRUCTION MANUAL
使用説明書


Voigtländer

**NOKTON
58mm F1.4 SL II**

Voigtländer

Voigtländer
NOKTON 58mm F1.4 SL II
Instruction Manual

● **Nomenclature Of Each Part**



- | | |
|------------------------|---------------------------|
| ① Filter Ring | ⑤ Aperture Scale |
| ② Distance Ring | ⑥ Distance/Aperture Index |
| ③ Distance Scale | ⑦ Aperture Ring |
| ④ Depth of field Scale | |

● **Attaching filter**

Use $\phi 58\text{mm}$ filter. Screw in the filter on Filter Ring ①.

● **Attaching Hood**

LH-58 is separately available as optional accessory. Screw in the Hood on Filter Ring ①.

● **Specifications**

Voigtländer NOKTON 58mm F1.4 SL II

Focal Length	58mm
Aperture Ratio	1:1.4
Smallest aperture	F16
Lens Construction	6 groups, 7 elements
Picture Angle	40°
Aperture blades	9
Nearest Distance	0.45m
Macro Ratio	1:5.8
Diameter	$\phi 64.4$
Filter Size	$\phi 58$
Length	47.5mm(Ai-S)
Weight	320g
Mounts	Ai-S(CPU integrated)
	KA
Optional accessory	Hood(LH-58)