


NOKTON 58mm F1.4 SLII
Instruction Manual

● Nomenclature Of Each Part



- | | |
|------------------------|---------------------------|
| ① Filter Ring | ⑥ Distance/Aperture Index |
| ② Distance Ring | ⑦ Aperture Ring |
| ③ Distance Scale | |
| ④ Depth of field Scale | |
| ⑤ Aperture Scale | |



NOKTON 58mm F1.4 SLII Instruction Manual

● Attaching Filter

Use $\Phi 58\text{mm}$ filter. Screw the filter into the Filter Ring ①.

● Attaching Hood

LH-58 is separately available as optional accessory.

Screw the Hood into the Filter Ring ①.

● Specifications

Voigtlander NOKTON 58mm F1.4 SLII

Focal Length	58mm
Aperture Ratio	1:1.4
Smallest aperture	F16
Lens Construction	6 groups, 7 elements
Picture Angle	40°
Aperture blades	9
Nearest Distance	0.45m
Macro Ratio	1 : 5.8
Diameter	$\phi 64.4$
Filter Size	$\phi 58$
Length	47.5mm (Ai-S)
Weight	320 g
Mounts	A I - S (CPU integrated), K A
Optional accessory	Hood (LH-58)